

High-Use Priority Groundwater Basins

- Priority Basins (116)
- Low Use Basins (356)
- Bedrock

GAMA Priority Basin selection based on:
95% public supply well locations
99% municipal well pumping
90% agricultural well pumping
90% leaking underground tanks
90% pesticide application
60% area of state